

LIEBAO

CS6

Diesel

Siemens Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Petrol

Siemens Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

Replace engine ECU

Replace immobiliser ECU

CS7

Immobiliser

DIAS immobiliser(UAES)

Delphi immobiliser(4G15)

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Input security code

Set security code

Program function

Program new system

Replace immobiliser ECU

Replace engine ECU

Program keys

Program engine VIN

Program immobiliser VIN

Reset engine ECU

Reset immobiliser

Erase keys

DIAS immobiliser(4G18)

Delphi immobiliser(4A15T)

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Input security code

Set security code

Program function

Program new system

Replace immobiliser ECU

Replace engine ECU

2016.05.15

- Program keys
- Program engine VIN
- Program immobiliser VIN
- Reset engine ECU
- Reset immobiliser
- Erase keys
- jicheng immobiliser(4A15T)
 - Program PIN
 - Input PIN
 - Program new keys
 - Program old keys
 - Erase keys
 - Program VIN
 - IMMO Rest
 - Program Date
 - Diagnosis Date
 - Program service station ID
 - EMS Reset
 - Program EMS
 - From EMS program IMMO
 - Offline program IMMO
 - Aftermarket replacement IMMO
 - Aftermarket replacement EMS
 - Aftermarket replacement key
- BCM
 - Erase Remote
 - Erase the first remote
 - Erase the second remote
 - Erase the third remote
 - Erase the fourth remote
 - Erase all remote
 - Remote learnning
 - Position 1 Learning
 - Position 2 Learning
 - Position 3 Learning
 - Position 4 Learning
- CS4
 - Immobiliser
 - jicheng immobiliser(4A15T)
 - Program PIN
 - Input PIN
 - Program new keys
 - Program old keys
 - Erase keys

- Program VIN
- IMMO Rest
- Program Date
- Diagnosis Date
- Program service station ID
- EMS Reset
- Program EMS
- From EMS program IMMO
- Offline program IMMO
- Aftermarket replacement IMMO
- Aftermarket replacement EMS
- Aftermarket replacement key

CS10

Immobiliser

- jicheng immobiliser(4A15T)(CAN_BUS)
- ECU reset
- Write configuration information
 - Vehicle production date
 - VIN
 - Service code
 - Loading Date
- Offline configuration
- Aftermarket replacement IMMO or EMS
- Aftermarket replacement key