

Geely

Geely

Yuanjing

STEC Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

Gleagle

Xiongmao

Immobiliser

STEC Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

- Erase key 2
- Erase key 3
- Erase key 4
- Erase key 5
- Replace immobiliser ECU
- Replace engine ECU
- Program immobiliser VIN
- Program engine VIN
- Reset engine ECU
- Reset immobiliser
- Immobiliser(UAES EMS)
 - ECU identification
 - Fault codes
 - Erase DTC
 - Live data
 - Set security code
 - Set security code
 - Input security code
 - Program function
 - Program new system
 - Program keys
 - Erase keys
 - Erase all keys
 - Erase key 1
 - Erase key 2
 - Erase key 3
 - Erase key 4
 - Erase key 5
 - Replace immobiliser ECU
 - Replace engine ECU
 - Program immobiliser VIN
 - Program engine VIN
 - Reset engine ECU
 - Reset immobiliser
- GX718
 - BCM
 - Lear BCM(KWP2000)
 - Immobiliser
 - STEC Immobiliser
 - ECU identification
 - Fault codes
 - Erase DTC
 - Live data
 - Set security code

- Set security code
- Input security code
- Program function
 - Program new system
 - Program keys
 - Erase keys
 - Erase all keys
 - Erase key 1
 - Erase key 2
 - Erase key 3
 - Erase key 4
 - Erase key 5
 - Replace immobiliser ECU
 - Replace engine ECU
 - Program immobiliser VIN
 - Program engine VIN
 - Reset engine ECU
 - Reset immobiliser

GX720

BCM

Continental BCM(CANBUS)

Immobiliser

STEC Immobiliser

- ECU identification
- Fault codes
- Erase DTC
- Live data
- Set security code
 - Set security code
 - Input security code
- Program function
 - Program new system
 - Program keys
 - Erase keys
 - Erase all keys
 - Erase key 1
 - Erase key 2
 - Erase key 3
 - Erase key 4
 - Erase key 5
 - Replace immobiliser ECU
 - Replace engine ECU
 - Program immobiliser VIN
 - Program engine VIN

Reset engine ECU
Reset immobiliser

GC7

Immobiliser

STEC Immobiliser

ECU identification
Fault codes
Erase DTC
Live data
Set security code
 Set security code
 Input security code
Program function
 Program new system
 Program keys
 Erase keys
 Erase all keys
 Erase key 1
 Erase key 2
 Erase key 3
 Erase key 4
 Erase key 5
 Replace immobiliser ECU
 Replace engine ECU
 Program immobiliser VIN
 Program engine VIN
 Reset engine ECU
 Reset immobiliser

PEPS

Steelmate PEPS

Read program result
Reset PEPS
Reset SHL
Program new system
Program SHL
Program PEPS
Program key and Remote

Emgrand

EC7

Immobiliser

Siemens Immobiliser
ECU identification
Fault codes
Erase DTC

- Live data
- Set security code
 - Set security code
 - Input security code
- Program function
 - Program new system
 - Program keys
 - Erase keys
 - Erase all keys
 - Erase key 1
 - Erase key 2
 - Erase key 3
 - Erase key 4
 - Erase key 5
 - Replace immobiliser ECU
 - Replace engine ECU
 - Program immobiliser VIN
 - Program engine VIN
 - Reset engine ECU
 - Reset immobiliser
- PEPS
 - Continental PEPS
 - Key Number
 - Key Program
 - Erase current key
 - Add 1 key
 - Add 2 keys
 - Not erase current key
 - Add 1 key
 - Add 2 keys
 - Other function
 - PEPS config
 - ESCI learn
 - PEPS erase ESK
 - ESCL erase ESK
 - After sale mode change
 - PEPS learn
- EC820
 - BCM
 - Lear BCM(KWP2000)
 - Lear BCM(CANBUS)
 - Add remote
 - UAES BCM(UDS)
 - Program keys

Immobiliser

STEC Immobiliser

- ECU identification
- Fault codes
- Erase DTC
- Live data
- Set security code
 - Set security code
 - Input security code
- Program function
 - Program new system
 - Program keys
 - Erase keys
 - Erase all keys
 - Erase key 1
 - Erase key 2
 - Erase key 3
 - Erase key 4
 - Erase key 5
 - Replace immobiliser ECU
 - Replace engine ECU
 - Program immobiliser VIN
 - Program engine VIN
 - Reset engine ECU
 - Reset immobiliser

Mitsubishi Immobiliser

- Fault codes
- Erase DTC
- Live data
- Program keys
- Reset immobiliser

PEPS

Steelmate PEPS

- Read program result
- Reset PEPS
- Reset SHL
- Program new system
- Program SHL
- Program PEPS
- Program key and Remote

EC825

BCM

- Lear BCM(KWP2000)
- Lear BCM(CANBUS)

Immobiliser

STEC Immobiliser

- ECU identification
- Fault codes
- Erase DTC
- Live data
- Set security code
 - Set security code
 - Input security code
- Program function
 - Program new system
 - Program keys
 - Erase keys
 - Erase all keys
 - Erase key 1
 - Erase key 2
 - Erase key 3
 - Erase key 4
 - Erase key 5
 - Replace immobiliser ECU
 - Replace engine ECU
 - Program immobiliser VIN
 - Program engine VIN
 - Reset engine ECU
 - Reset immobiliser

Mitsubishi Immobiliser

- Fault codes
- Erase DTC
- Live data
- Program keys
- Reset immobiliser

PEPS

Steelmate PEPS

- Read program result
- Reset PEPS
- Reset SHL
- Program new system
- Program SHL
- Program PEPS
- Program key and Remote

Hella PEPS

- Key program in the new system
- After sales key program
- Program new system

After sales system program
Erase learning state
 Erase ESCL learning state
 Erase EMS learning state
 Erase PEPS learning state
Read learning state

EX8

Immobiliser

STEC Immobiliser
 ECU identification
 Fault codes
 Erase DTC
 Live data
 Set security code
 Set security code
 Input security code
 Program function
 Program new system
 Program keys
 Erase keys
 Erase all keys
 Erase key 1
 Erase key 2
 Erase key 3
 Erase key 4
 Erase key 5
 Replace immobiliser ECU
 Replace engine ECU
 Program immobiliser VIN
 Program engine VIN
 Reset engine ECU
 Reset immobiliser

EV8

PEPS

Hella PEPS
 Key program in the new system
 After sales key program
 Program new system
 After sales system program
 Erase learning state
 Erase ESCL learning state
 Erase EMS learning state
 Erase PEPS learning state
 Read learning state

Maple

Immobiliser

STEC Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

Englon

TX4

Immobiliser

Integrated BCM(Delphi EMS)

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

SC515

Immobiliser

STEC Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

SC7

Immobiliser

STEC Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

2016.05.15

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

SC6

Immobiliser

STEC Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

PEPS

Steelmate PEPS

- Read program result
- Reset PEPS
- Reset SHL
- Program new system
- Program SHL
- Program PEPS
- Program key and Remote

SC3

Immobiliser

Immobiliser(UAES EMS)

- ECU identification
- Fault codes
- Erase DTC
- Live data
- Set security code
 - Set security code
 - Input security code
- Program function
 - Program new system
 - Program keys
 - Erase keys
 - Erase all keys
 - Erase key 1
 - Erase key 2
 - Erase key 3
 - Erase key 4
 - Erase key 5
 - Replace immobiliser ECU
 - Replace engine ECU
 - Program immobiliser VIN
 - Program engine VIN
 - Reset engine ECU
 - Reset immobiliser

SX7

PEPS

Hella PEPS

- Key program in the new system
- After sales key program
- Program new system
- After sales system program
- Erase learning state
 - Erase ESCL learning state
 - Erase EMS learning state

- Erase PEPS learning state
- Read learning state
- Jingang(CROSS)
 - Immobiliser
 - STEC Immobiliser
 - ECU identification
 - Fault codes
 - Erase DTC
 - Live data
 - Set security code
 - Set security code
 - Input security code
 - Program function
 - Program new system
 - Program keys
 - Erase keys
 - Erase all keys
 - Erase key 1
 - Erase key 2
 - Erase key 3
 - Erase key 4
 - Erase key 5
 - Replace immobiliser ECU
 - Replace engine ECU
 - Program immobiliser VIN
 - Program engine VIN
 - Reset engine ECU
 - Reset immobiliser
- PEPS
 - Steelmate PEPS
 - Read program result
 - Reset PEPS
 - Reset SHL
 - Program new system
 - Program SHL
 - Program PEPS
 - Program key and Remote