



NitroData [Chip Tuning Box] for Motorbikers

KTM 990 ADVENTURE/S SUPER DUKE SUPERMOTO

- 1) REMOVE THE SADDLE
- 2) REMOVE THE TANK DOING VERY CAREFUL NOT
BEND OF THE FUEL HOSE, THE HOSE AND REMOVE THE TANK
- 3) ON TOP OF THE CASE ARE THE FILTER SENSOR T. AIR (PHOTO),
SGANCIATELO AND FITTED WITH ON THE **NITRODATA** SPINE
- 4) PLACE THE UNIT WITH THE WARNING AREA UNDER THE SADDLE

