



## NitroData [Chip Tuning Box] for Motorbikers

### BMW R1150R RT

- 1) REMOVE THE SEAT OF THE PILOT
- 2) REMOVE THE RIGHT SIDE OF THE BIKE
- 3) ON THE BACK SIDE BOTTOM SIDE OF THE THROTTLE BODY FIND THE SENSOR T. AIR (PICTURES), AND MOUNTED THE SGANCIATELO NITRODATA RELATING TO THE SPINE
- 4) PLACE THE UNIT WITH THE WARNING AREA UNDER THE SADDLE

