



NitroData [Chip Tuning Box] for Motorbikers

BMW F800 S

- 1) REMOVE THE PLASTIC OVER THE CENTRAL FAKE TANK
- 2) ON TOP OF THE CASE ARE THE FILTER SENSOR T. AIR (PHOTO), SGANCIATELO AND FITTED WITH ON THE NITRODATA SPINE
- 3) PLACE THE UNIT WITH THE WARNING AREA MORE ' COMFORTABLE

