



NitroData [Chip Tuning Box] for Motorbikers

HONDA CBR 600 F SPORT

- 1) REMOVE THE SADDLE
- 2) REMOVE THE SIDE PLASTIC TANK
- 3) REMOVE THE SCREWS OF TANK TURNING THE SCREWS 4 4) TANK RAISED
THE ABOVE CASE TO FIND THE FILTER AIR TEMPERATURE SENSOR, AND
INSTALL THE PLUG Unclip **NITRODATA** (SEE PHOTO) SPINE WITH THE PROPER

