



NitroData [Chip Tuning Box] for Motorbikers

SUZUKI SV 650 N

- 1) REMOVE THE PASSENGER SEAT + PILOT
- 2) REMOVE THE 2 SCREWS IN THE TANK BRACKET
- 3) RAISE THE TANK DOING VERY CAREFUL NOT BEND OF THE FUEL HOSE, THE HOSE AND REMOVE THE TANK
- 4) ON THE BACK OF THE CASE ARE THE FILTER SENSOR T. AIR (PHOTO), SGANCIATELO AND FITTED WITH ON THE **NITRODATA** SPINE
- 5) CAREFULLY PLACE THE UNIT IN THE AREA UNDER THE SADDLE

