



## NitroData [Chip Tuning Box] for Motorbikers

### BMW K1200 RS

- 1) REMOVE THE PASSENGER SEAT + PILOT
- 2) REMOVE THE SIDE LATERAL RAISE AND THE TANK
- 3) ON THE BOTTOM OF THE CASE ARE THE FILTER SENSOR T. AIR (PHOTO), SGANCIATELO AND FITTED WITH ON THE NITRODATA SPINE
- 4) PLACE THE UNIT WITH THE WARNING AREA UNDER THE SADDLE

