



NitroData [Chip Tuning Box] for Motorbikers

KTM SMC 690

- 1) REMOVE THE SADDLE
- 2) REMOVE THE SIDE LEFT SIDE
- 3) ON THE RIGHT SIDE OF CASH INFIORE FILTER FIND SENSOR T. AIR (PHOTO), SGANCIATELO AND FITTED WITH THE **NITRODATA** ON THORNS
- 4) PLACE THE UNIT WITH THE WARNING AREA UNDER THE SADDLE

