

---

**TRUMPMCHI(EPB)**

GS5

Erase DTC

EPB Operation mode

Parking

Shielded EPB switch operation

Release to assembly position

Initialization

Release

Force calibration

EPB Running

300N,300m

500N,500m

1000N,1000m

Position lamp relay fault