

## Immobiliser Function List

**Software Version: 26.15**

Automaker	Model/Protocol	System	Function
BRILLIANCE(Zhonghua)	1.Old Zhonghua 2.Zunchi 3.Junjie 4.Kubao 5.Junjie FRV 6.Junjie FSV	Mitsubishi Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
BRILLIANCE(Zhonghua)	1.Zunchi 2.Junjie 3.Kubao	Delphi Immobiliser	1.ECU identification 2.Fault codes 3.Erase DTC 4.Live data 5.Program function (1)Program new system (2)Replace immobiliser ECU (3)Replace engine ECU (4)Program keys (5)Program engine VIN (6)Program immobiliser VIN (7)Reset engine ECU (8)Reset immobiliser (9)Erase keys

BRILLIANCE(Zhonghua)	1.Zunchi 2.Junjie 3.Kubao 4.Junjie FRV 5.Junjie FSV 6.Junjie CROSS 7.Junjie WAGON 8.H230 9.H320 10.H330 11.H530 12.V5	Siemens Immobiliser	1.ECU identification 2.Fault codes 3.Erase DTC 4.Live data 5.Program function (1)Program new system (2)Program keys<ACT2> (3)Replace immobiliser ECU (4)Replace engine ECU (5)Program mechanical key number (6)Program engine VIN (7)Program WSC (8)Reset engine ECU (9)Reset immobiliser
BRILLIANCE(Zhonghua)	FSV	PEPS old smart key	1.Program smart keys
BRILLIANCE(Zhonghua)	1.FSV 2.H330	PEPS new smart key	1.Fault codes 2.Erase DTC 3.Program function (1)Program smart keys (2)Program new system (3)Reset engine ECU (4)Reset immobiliser
BRILLIANCE(Zhonghua)	1.H530 2.V5	PEPS smart key diag	1.ECU identification 1 2.ECU identification 2 3.Fault codes 4.Erase DTC 5.Live data 6Automatic test 7.Write VIN
BRILLIANCE(Zhonghua)	1.H530 2.V5	PEPS smart key program	1.Program new system 2.Program smart keys 3.Program PEPS 4.Reset PEPS 5.Program ESCL

BRILLIANCE(Jinbei)		Delphi Immobiliser	1.ECU identification 2.Fault codes 3.Erase DTC 4.Live data 5.Program function (1)Program new system (2)Replace immobiliser ECU (3)Replace engine ECU (4)Program keys (5)Program engine VIN (6)Program immobiliser VIN (7)Reset engine ECU (8)Reset immobiliser (9)Erase keys
BRILLIANCE(Jinbei)	H2	Siemens Immobiliser	1.ECU identification 2.Fault codes 3.Erase DTC 4.Live data 5.Program function (1)Program new system (2)Program keys<ACT2> (3)Replace immobiliser ECU (4)Replace engine ECU (5)Program mechanical key number (6)Program engine VIN (7)Program WSC (8)Reset engine ECU (9)Reset immobiliser