

Immobiliser Function List

Software Version: 26.41

Automaker	Model/Protocol	System	Function
JAC	S5 1.5T	Immobiliser	<ol style="list-style-type: none"> 1. Number of keys> 2. Add a old key 3. Add a new key 4. Erase keys 5. Reset immobiliser 6. Replace immobiliser 7. Reset engine ECU 8. Replace engine ECU 9. Program all new systems
JAC	Binyue	Immobiliser(Delphi)	<ol style="list-style-type: none"> 1. ECU identification 2. Fault codes 3. Erase DTC 4. Live data 5. Set security code <ol style="list-style-type: none"> (1)Input security code (2)Set security code 6. Program function <ol style="list-style-type: none"> (1)Program new system (2)Replace immobiliser ECU (3)Replace engine ECU (4)Program keys (5)Program engine VIN (6)Program immobiliser VIN (7)Reset engine ECU (8)Reset immobiliser (9)Erase keys

JAC	Binyue	Immobiliser(DIAS)	<ol style="list-style-type: none"> 1. ECU identification 2. Fault codes 3. Erase DTC 4. Live data 5. Program function <ol style="list-style-type: none"> (1) Add a key (2) Erase keys (3) Program new system (4) Replace immobiliser ECU (5) Replace engine ECU (6) Reset immobiliser (7) Reset engine ECU (8) Read VIN (9) Check key (10) Check engine ECU (11) Program engine VIN (12) Program immobiliser VIN (13) Lock immobiliser 6. Actuation test
JAC	Tongyue	Immobiliser(Delphi)	<ol style="list-style-type: none"> 1. ECU identification 2. Fault codes 3. Erase DTC 4. Live data 5. Set security code <ol style="list-style-type: none"> (1)Input security code (2)Set security code 6. Program function <ol style="list-style-type: none"> (1)Program new system (2)Replace immobiliser ECU (3)Replace engine ECU (4)Program keys (5)Program engine VIN (6)Program immobiliser VIN (7)Reset engine ECU (8)Reset immobiliser (9)Erase keys

JAC	Tongyue	Immobiliser(DIAS)	<ol style="list-style-type: none"> 1. ECU identification 2. Fault codes 3. Erase DTC 4. Live data 5. Program function <ol style="list-style-type: none"> (1) Add a key (2) Erase keys (3) Program new system (4) Replace immobiliser ECU (5) Replace engine ECU (6) Reset immobiliser (7) Reset engine ECU (8) Read VIN (9) Check key (10) Check engine ECU (11) Program engine VIN (12) Program immobiliser VIN (13) Lock immobiliser 6. Actuation test
JAC	Heyue RS	Immobiliser(Delphi)	<ol style="list-style-type: none"> 1. ECU identification 2. Fault codes 3. Erase DTC 4. Live data 5. Set security code <ol style="list-style-type: none"> (1)Input security code (2)Set security code 6. Program function <ol style="list-style-type: none"> (1)Program new system (2)Replace immobiliser ECU (3)Replace engine ECU (4)Program keys (5)Program engine VIN (6)Program immobiliser VIN (7)Reset engine ECU (8)Reset immobiliser (9)Erase keys

JAC	Heyue RS	Immobiliser(DIAS)	<ol style="list-style-type: none"> 1. ECU identification 2. Fault codes 3. Erase DTC 4. Live data 5. Program function <ol style="list-style-type: none"> (1) Add a key (2) Erase keys (3) Program new system (4) Replace immobiliser ECU (5) Replace engine ECU (6) Reset immobiliser (7) Reset engine ECU (8) Read VIN (9) Check key (10) Check engine ECU (11) Program engine VIN (12) Program immobiliser VIN (13) Lock immobiliser 6. Actuation test
JAC	Heyue car	Immobiliser(Delphi)	<ol style="list-style-type: none"> 1. ECU identification 2. Fault codes 3. Erase DTC 4. Live data 5. Set security code <ol style="list-style-type: none"> (1)Input security code (2)Set security code 6. Program function <ol style="list-style-type: none"> (1)Program new system (2)Replace immobiliser ECU (3)Replace engine ECU (4)Program keys (5)Program engine VIN (6)Program immobiliser VIN (7)Reset engine ECU (8)Reset immobiliser (9)Erase keys

JAC	Heyue car	Immobiliser(DIAS)	1. ECU identification 2. Fault codes 3. Erase DTC 4. Live data 5. Program function (1) Add a key (2) Erase keys (3) Program new system (4) Replace immobiliser ECU (5) Replace engine ECU (6) Reset immobiliser (7) Reset engine ECU (8) Read VIN (9) Check key (10) Check engine ECU (11) Program engine VIN (12) Program immobiliser VIN (13) Lock immobiliser 6. Actuation test
JAC	Yueyue	Immobiliser(Delphi)	1. ECU identification 2. Fault codes 3. Erase DTC 4. Live data 5. Set security code (1)Input security code (2)Set security code 6. Program function (1)Program new system (2)Replace immobiliser ECU (3)Replace engine ECU (4)Program keys (5)Program engine VIN (6)Program immobiliser VIN (7)Reset engine ECU (8)Reset immobiliser (9)Erase keys

JAC	Yueyue	Immobiliser(DIAS)	<ol style="list-style-type: none"> 1. ECU identification 2. Fault codes 3. Erase DTC 4. Live data 5. Program function <ol style="list-style-type: none"> (1) Add a key (2) Erase keys (3) Program new system (4) Replace immobiliser ECU (5) Replace engine ECU (6) Reset immobiliser (7) Reset engine ECU (8) Read VIN (9) Check key (10) Check engine ECU (11) Program engine VIN (12) Program immobiliser VIN (13) Lock immobiliser 6. Actuation test
JAC	Heyue A30 MT	Immobiliser(DIAS)	<ol style="list-style-type: none"> 1. ECU identification 2. Fault codes 3. Erase DTC 4. Live data 5. Program function <ol style="list-style-type: none"> (1) Add a key (2) Erase keys (3) Program new system (4) Replace immobiliser ECU (5) Replace engine ECU (6) Reset immobiliser (7) Reset engine ECU (8) Read VIN (9) Check key (10) Check engine ECU (11) Program engine VIN (12) Program immobiliser VIN (13) Lock immobiliser 6. Actuation test

JAC	Heyue A30 CVT	Immobiliser(DIAS)	1. ECU identification 2. Fault codes 3. Erase DTC 4. Live data 5. Program function (1) Add a key (2) Erase keys (3) Program new system (4) Replace immobiliser ECU (5) Replace engine ECU (6) Reset immobiliser (7) Reset engine ECU (8) Read VIN (9) Check key (10) Check engine ECU (11) Program engine VIN (12) Program immobiliser VIN (13) Lock immobiliser 6. Actuation test
JAC	Heyue A30 CVT	Smart Key System(PEPS)	1. Number of keys 2. Escl learn 3. Add key 4. Replace engine ECU
JAC	10 PIN	Remote	Type 1
JAC	10 PIN	Remote	Type 2
JAC	Heyue - 16 PIN	Remote	
JAC	Tongyue - 16 PIN	Remote	
JAC	Binyue - 16 PIN	Remote	
JAC	Tricyclic - 16 PIN	Remote	
JAC	Ruifeng S3 - 16 PIN	Remote	
JAC	Ruifeng S5 - 16 PIN	Remote	
JAC	Ruifeng Hechang - 16 PIN	Remote	
JAC	Heyue A30(CVT) - 16 PIN	Remote	