

Immobiliser Function List

Software Version: 26.20

Automaker	Model	System	Function
CHANGHE	Liana	Immobiliser 1	1. Live data 2. Program keys 3. Erase keys
CHANGHE	Liana	Immobiliser 2	1. ECU identification 2. Fault codes 3. Erase DTC 4. Live data 5. Program function (1) VIN code conversion security code (2) Replace engine ECU (3) Replace immobiliser ECU (4) Add a new keys (5) Re-program keys (6) Erase keys (7) Reset immobiliser (8) Reset engine ECU (9) Program VIN (10) Check key (11) Lock immobiliser (12) Activation of the engine ECU
CHANGHE	Liana	Smart key system	1. New PEPS learn 2. Old PEPS learn 3. Learning the Key(smart) 4. Learning the Key(IMMO) 5. Learning the SLU(Steering solenoid valve) 6. Reset EMS(Engine computer) 7. Learning the EMS(Engine computer)

CHANGHE	Splash	Immobiliser	1. ECU identification 2. Fault codes 3. Erase DTC 4. Live data 5. Program function (1) VIN code conversion security code (2) Replace engine ECU (3) Replace immobiliser ECU (4) Add a new keys (5) Re-program keys (6) Erase keys (7) Reset immobiliser (8) Reset engine ECU (9) Program VIN (10) Check key (11) Lock immobiliser (12) Activation of the engine ECU
CHANGHE	Splash	Tung Thih Immobiliser(G5)	1. Engine ECU Match 2. Anti-theft ECU Match 3. Key Match 4. EMS reset
CHANGHE	Wagon R	Immobiliser	1. ECU identification 2. Fault codes 3. Erase DTC 4. Live data 5. Program function (1) VIN code conversion security code (2) Replace engine ECU (3) Replace immobiliser ECU (4) Add a new keys (5) Re-program keys (6) Erase keys (7) Reset immobiliser (8) Reset engine ECU (9) Program VIN (10) Check key (11) Lock immobiliser (12) Activation of the engine ECU