

Immobiliser Function List

Software Version: 26.02

Automaker	Model/Protocol	System	Function
MERCURY	Cougar(1999-2002)	Immobiliser	1.Number of keys in Memory 2.Add a key 3.Erase all keys
MERCURY	Gr.Marqui(2005-2010)	Immobiliser	1.Number of keys 2.Add a key 3.Erase all keys
MERCURY	Gr.Marqui (2003-2004)	Immobiliser	1.Number of keys in Memory 2.Add a key 3.Erase all keys
MERCURY	Marauder (2003-2005)	Immobiliser	1.Number of keys in Memory 2.Add a key 3.Erase all keys
MERCURY	Mariner(2010-)	Immobiliser	1.Number of keys 2.Add a key 3.Erase all keys
MERCURY	Mariner(2008-2009)	Immobiliser	1.Number of keys 2.Add a key 3.Erase all keys
MERCURY	Mariner(2005-2007)	Immobiliser	1.Number of keys 2.Add a key 3.Erase all keys
MERCURY	Milan(2010-)	Immobiliser	1.Number of keys 2.Add a key 3.Erase all keys
MERCURY	Milan(2006-2009-)	Immobiliser	1.Number of keys 2.Add a key 3.Erase all keys
MERCURY	Montego(2007-)	Immobiliser	1.Number of keys 2.Add a key 3.Erase all keys

MERCURY	Montego(2005-2006)	Immobiliser	1.Number of keys 2.Add a key 3.Erase all keys
MERCURY	Monterey(2006-2007)	Immobiliser	1.Number of keys 2.Add a key 3.Erase all keys
MERCURY	Monterey(2004-2005)	Immobiliser	1.Number of keys in Memory 2.Add a key 3.Erase all keys
MERCURY	M.Taineer(2010-)	Immobiliser	1.Number of keys 2.Add a key 3.Erase all keys
MERCURY	M.Taineer(2006-2009)	Immobiliser	1.Number of keys 2.Add a key 3.Erase all keys
MERCURY	M.Taineer(2004-2005)	Immobiliser	1.Number of keys 2.Add a key 3.Erase all keys
MERCURY	M.Taineer[PCM] (2001-2004)	Immobiliser	1.Number of keys in Memory 2.Add a key 3.Erase all keys
MERCURY	Sable(2008-)	Immobiliser	1.Number of keys 2.Add a key 3.Erase all keys
MERCURY	Sable(2004-2007)	Immobiliser	1.Number of keys 2.Add a key 3.Erase all keys
MERCURY	Sable(2000-2003)	Immobiliser	1.Number of keys in Memory 2.Add a key 3.Erase all keys