

Immobiliser Function List

Software Version: 26.10

Automaker	Model/Protocol	System	Function
HNMAZDA	STEC Immobiliser system	Immobiliser	1.ECU identification 2.Fault codes 3.Erase DTC 4.Live data 5.Set security code (1)Set security code (2)Input security code 6.Program function (1)Program new system (2)Program keys (3)Erase keys (4)Replace immobiliser ECU (5)Replace engine ECU (6)Program immobiliser VIN (7)Program engine VIN (8)Reset engine ECU (9)Reset immobiliser
HNMAZDA	DIAS Immobiliser	Immobiliser	1.ECU identification 2.Fault codes 3.Erase DTC 4.Live data 5.Program function 6.Actuation test

HNMAZDA	IMMO(DIAS-Immobiliser Controller-M8)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Immobiliser state 5.Read PIN 6.Write data 7.ECU reset 8.Program function
HNMAZDA	Immobiliser Controller(M3)	Immobiliser	1.Live data 2.ECU reset (1)Power (2)Original 3.Write data (1)Write VIN (2)Write PIN 4.Program function (1)Add a new key (2)Add a old key (3)Erase all keys (4)Generate SK (5)Get SK from engine module (6)Learning ECM's PIN and SK2 (7)Lock ECU (8)Check key (9)Check ECM (10)ECM reset

HNMAZDA	Immobiliser Controller(M6/S5 Without smart)	Immobiliser	1.Live data 2.ECU reset (1)Hard Reset (2)Unlock ECU 3.Write data (1)Write VIN (2)Write PIN 4.Program function (1)Add a new key (2)Add a old key (3)Erase all keys (4)Generate SK2 (5)The SK2 of ECM Self-learning (6)Learning ECM's SK2 (7)Lock ECU (8)Check key (9)Check ECM (10)Learning ECM's PIN (11)ECM reset
---------	--	-------------	--

HNMAZDA	Immobiliser Controller(M6/S5 With smart)	Immobiliser	1.Live data 2.ECU reset (1)Hard Reset (2)Unlock ECU 3.Write data (1)Write VIN (2)Write PIN 4.Program function (1)Add a new key (2)Add a old key (3)Erase all keys (4)Generate SK2 (5)The SK2 of ECM Self-learning (6)Learning ECM's SK2 (7)Lock ECU (8)Check key (9)Check ECM (10)Learning ECM's PIN (11)ECM reset
HNMAZDA	Immobiliser Controller(S7)	Immobiliser	1. Identification 2. Read fault memory 3. Clear fault memory 4. Data stream 5. Match the key 6. Erase all keys 7. Program new system 8. Alarm change 9. ECM change
HNMAZDA	Kingdom Body Control(M3/M6)	Remote	1.Program remote
HNMAZDA	Tongzhi Body Control(M3)	Remote	1.Program remote
HNMAZDA	Body Control system(M6)	Remote	1.Program remote
HNMAZDA	Body Control system(S5)	Remote	1.Program remote